


# FINISH KEY

## FLOORS



- A – REMOVE EXISTING VCT FLOORING. INSTALL NEW SHEET VINYL FLOORING. BASIS OF DESIGN IS ARMSTRONG VENTARA VINYL SHEET FLOORING.
- B – REMOVE EXISTING FLOORING IN AREA OF BELOW FLOOR PLUMBING AND TO WITHIN 2' +/- OF WALLS. PROVIDE NEW FLOOR PER FLOOR C.
- C – REMOVE EXISTING VCT FLOORING. PROVIDE NEW 1/8" GAGE VCT FLOORING. BASIS OF DESIGN IS AZROCK STANDARD VCT.

## BASE

- 1 – REMOVE EXISTING BASE. INSTALL NEW 4" VINYL BASE INTEGRAL WITH SHEET FLOORING. PROVIDE ALUMINUM TERMINATION BAR.
- 2 – EXISTING BASE REMAINS. NO WORK.
- 3 – REMOVE EXISTING RESILIENT BASE. PROVIDE NEW 4" RESILIENT BASE.

## WALLS

- A – NO WORK
- B – PAINT W/ 2-COAT LATEX ENAMEL (EGGSHELL).
- C – 6" METAL STUDS AND 1/2" GWB WITH 3-COAT LATEX ENAMEL (EGGSHELL) ABOVE GLAZED WALL TILE WAINSCOT.